

TECHNICAL BULLETIN ULTERION® 4300 Dye Leveler & Fixative



- Dye leveling
- Dye bath lubricant

Product Description

Ulterion® 4300 is an anionic polyacrylamide polymer supplied as an emulsion. It has wide use as a dye bath lubricant in textile processing applications. Ulterion® 4300 is a high molecular weight, highly cationic polyamine coagulant used as a dye fixative in VAT dyeing operations

Typical Properties

| Appearance | Opaque liquid |
|-----------------------------------|---------------|
| Ionic Character | Anionic |
| Charge Density | Low |
| Molecular Weight | High |
| Approx. Bulk Density | 1.03 |
| Active Content (%) | 29 |
| Bulk viscosity (cps) | 1200 |
| Maximum Concentration (g/l) | 5 |
| Stability of D.I. solution (days) | 8 |
| Approx. Viscosity | 1000 |
| (5 g/l active content (cps)) | |
| Storage Temperature (°C) | 0 - 35 |
| Shelf Life (months)* | 6 |

*When stored inside a building at a stable temperature between 5° and 30 °C

Application Methods

Ulterion® 4300 promotes adhesion of the processing bath to fabric. Creasing and chafe marks can be reduced by lowering the coefficient of friction at the fabric's surface. A bath concentration of 2-4% polymer is recommended. Addition should occur early in the bath. *Ulterion*® 4300 controls friction with most fibers

MARKET USES

Textile dyeing

Handling / Storage Stability

Ulterion® 4300 should be stored in a temperature-controlled environment. Insulated tanks are recommended for bulk storage. These products are freeze-thaw stable. However, if frozen, product must be mixed thoroughly prior to use. It is recommended to keep Ulterion® 4300 from freezing. For spills of Ulterion® 4300 sprinkle sawdust or vermiculite over the spill area and sweep the material into approved chemical disposal containers.

Product Safety

When considering the use of **Ulterion International** products, please refer to the latest Material Safety Data Sheets (MSDS). If you require an MSDS for this product; please call (770) 579-0552 or your **Ulterion International Representative**.

Ulterion International, LLC P.O. Box 236 Braselton, GA 30517 Phone: 706-654-2222 Fax: 706-654-2234 www.ulterion.com

